

Installation manual USB-Driver for PICOGLOSS 560 II MC (Windows XP)

(Note: The driver itself has no "language" dependant parts; so this driver can be used in all countries and for all languages)


1. When you have downloaded the driver from the Internet, save the file "USB_Driver.exe" on the hard drive of your computer. This file is a self-extracting archive. Start the file USB_Driver.exe and the driver files will be unpacked. Later in the installation process you will need to know the path of the unpacked files; i. e.: the path, where the files are stored on the hard drive.
2. Now connect the PICOGLOSS 560 with the provided USB cable to your computer. After a few seconds, the Windows Wizard for searching for new hardware appears.



3. If Windows ask you, if you want to make a connection to Windows Update, choose the option „No, not this time“and then click “Next”.



4. Select the option „Install from a list or specific location (Advanced)“ and then „Next“.



5. Select the option „Include this location in the search:“ and indicate the position, To do this, click onto the button “Browse” and select the path, where you have saved the unpacked driver files. Then click “Next”.



6. After completing the Hardware Wizard, you can start the Setup programme of PICOGLOSS II 560 MC and install the application.